Guide de l'utilisateur

GT125

Passerelle Web

sinopé

Votre Passerelle Web GT125

État de la connexion Web :
Verte = La passerelle est connectée au serveur « neviweb »

État de la connectivité sans fil :
Ambre = Recherche un réseau
Clignote verte = Prêt pour ajouter de nouveaux appareils
Verte = Le réseau est opérationel
Rouge = Consulter le site Web pour faire le dépannage de l'unité

Installer votre passerelle

Branchez votre GT125 à votre routeur Internet à l 'aide du câble Ethernet et branchez l'adaptateur d'alimentation.

Lorsque branchée, la passerelle se connecte automatiquement au serveur « neviweb ».



L'antenne interne du GT125 diffuse de façon optimale lorsque ce dernier est installé en position verticale tel qu'indiqué ci-dessus.

Relier votre réseau à « neviweb »

Allez au **www.neviweb.com** afin d'ajouter votre réseau.

Si c'est votre première visite :

- Appuyez sur S'enregister pour créer votre compte.
- Entrez les informations demandées et appuyez sur Enregistrer. Un courriel vous sera envoyé pour activer votre compte.
- Ajouter votre réseau à votre compte en enregistrant la passerelle.

Si vous avez déjà un compte :

- Entrez votre courriel ainsi que votre mot de passe et appuyez sur Ouvrir une session.
- Appuyez sur « mon compte », qui est situé dans le coin supérieur droit de la fenêtre et sélectionner « ajouter un réseau ».

Note: Pour enregistrer votre passerelle, vous devez entrer le numéro ID situé à l'arrière de celle-ci.

Lorsque terminé, pour des raisons de sécurité, vous devrez confirmer l'opération en appuyant sur le bouton « Web » de votre passerelle.

Relier vos produits « neviweb » à votre passerelle

Pour créer votre réseau sans fil, référez-vous au guide de l'utilisateur de votre produit « neviweb ».

Module transmetteur IC : 7693A-89XAM9A

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne produit pas de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Garantie limitée de 3 ans

SINOPÉ TECHNOLOGIES INC. garantit les composantes de ses produits, contre les vices et les défauts de fabrication en fonction d'une utilisation et d'entretiens normaux, et ce, pour une période de 3 ans à partir de la date d'achat et sur présentation d'une facture attestant cette date. La garantie ne prévoit pas le remboursement des frais de transport encourus par le consommateur et ne s'applique pas à un produit qui aurait été mal installé, mal utilisé ou accidentellement endommagé. La responsabilité de Sinopé Technologies Inc. se limite uniquement au remplacement du produit (appareil) et ne comprend d'aucune façon le coût de branchement ou de la pose de l'appareil ou pièces de remplacement.

Pour plus d 'information, visitez notre site Web :
www.sinopetech.com

neviweb

660-0125-0000-B

User's guide

GT125

Web Gateway

sinopé

Your GT125 Web Gateway

Web connection Status:
Green = The gateway is connected to the "neviweb" server

Wireless Network Status:
Amber = Searching for a network
Flashes green = Ready to add a new device
Green = The network is operational
Red = Refer to our website to troubleshoot the unit

Install your gateway

Connect your GT125 to your internet router using the provided Ethernet cable and connect the power adapter.

When connected, the gateway will automatically connect to the "neviweb" server.



The best diffusion pattern for the internal antenna is reached when the GT125 is installed vertically as shown above.

Link your network to "neviweb"

Go to **www.neviweb.com** to add your network.

If it 's your first visit:

- Select Register to create your account.
- Enter the requested information, then press Save. An e-mail will be sent to you to activate your account.
- Add your network to your account by registering the gateway.

If you already have an account:

- Enter your e-mail and your password then press Sign in.
- Press on "my account", located at the upper right corner then select "add a network".

Note: To register your gateway, you will be asked to enter the ID number located on the back of your gateway.

Once completed, for security reasons, you will have to confirm the operation by pressing the "Web" button on your gateway.

Link your "neviweb" products to your gateway

To create your wireless network, refer to your "neviweb" compatible product's user's guide.

Transmitter Module IC: 7693A-89XAM9A / FCC ID:OA3MRF89XAM9A

This device complies with Industry Canada license exempt RSS standard(s). Operation is subject to the following two conditions:
(1) this device does not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

3-year limited warranty

SINOPÉ TECHNOLOGIES INC. warrants the components of their products against defects in material and workmanship for a 3 year period from the date of purchase, under normal use and service, when proof of purchase of such is provided to the manufacturer. This warranty does not cover any transportation costs that may be incurred by the consumer. Nor does it cover a product subjected to misuse or accidental damage. The obligation of Sinopé Technologies Inc., under the terms of this warranty, will be to supply a new unit and this releases the manufacturer from paying the installation costs or other secondary charges linked to replacing the unit or the components.

For more information, visit our website at:
www.sinopetech.com

neviweb

660-0125-0000-B